

AIR CONDITIONER FILTER




Inspection guideline (Replace if necessary)

	Interval		
Severe driving condition	15,000 km	1 year	*whichever comes first
Normal driving condition	30,000 km	2 years	

Purpose and Function

Air conditioner filter blocks dust, pollen, sand and mites, etc. and supplies clean air to the automobile cabin.



If overused without replacement ...

- **Poor ventilation**
- **Inefficient air conditioning**
- **Longer time require to clear frost from windshield**

The air conditioner filter is a consumable part, composed of fibers which block dust and particulates.

When used over a long period of time, it will become clogged.

As a result it will not be able to keep your automobile cabin clean and comfortable. In addition, the efficiency of the air conditioning system will be reduced.